## Winger Electronics SOLAROX® Mini Dimmer

**DIMM 5-24-4A** 

Spannungsbereich / Voltage Range:	524V DC
Belastbarkeit / Load:	4A



## Installation

- 1. Verbinden Sie die LED mit der M12-Buchse des Controllers. Achten Sie auf die richtige Polung.
- 2. Verbinden Sie den M12-Stecker des Controllers mit dem passenden Netzteil. Der Eingangsspannungsbereich des Controllers beträgt 5-24V DC.
- 1. Connect LED with controller. Pay attention for polarity.
- 2. Connect controller with matching power supply. Input voltage range is 5-24V DC.

## **Bedienung / Operation**

- 1. **MODE** Taste: Schaltet in den dynamischen Betrieb. Mehrfaches Drücken wechselt zwischen 8 verschiedenen Programmen.
- 2. **SPEED/BRIGHT/OFF** Taste: Einstellung Geschwindigkeit im dynamischen Betrieb oder Verringerung Helligkeit im Dimmbetrieb. Längerer Druck >1s schaltet das Gerät aus.
- 3. **LIGHT/Brightness** Taste: Schaltet in den Dimmbetrieb. Jeder Druck erhöht die Helligkeit. Längerer Druck >1s schaltet auf 100% Helligkeit.
- 1. **MODE** key: Switch to dynamic mode. Press this key to switch among 8 dynamic modes.
- 2. **SPEED/BRIGHT/OFF** key: Adjust speed in dynamic mode or decrease brightness in static dimming mode. Press and hold >1sec turns power off.
- 3. **LIGHT/Brightness** key: Switch to static dimming mode. Press to increase brightness. Press and hold for 1 second to jump to 100% brightness.